


GolfGrips-Direct

Solvent Activated

Regripping your Golf Clubs


We recommend you read through all 10 steps before beginning!

1




Ideally, secure your club in a vice near the grip end using a protective [Vinyl Rubber Vice Clamp](#). Position the club perpendicular to the floor in the playing position. If you do not have a vice go to section 2 as a vice helps regripping, but is not essential.

2




Remove the old grip with a [hook blade](#). If you do not have a hook blade use a sharp knife but pay particular attention not to score or cut a graphite shaft as it will weaken it. Peel off all old tape by hand and clean up the residue with a solvent (e.g. White spirit) if required.

3




Hold the new grip next to the cleaned shaft butt to determine how much of the area needs to be covered by the grip strip. All Golf Grip Direct's [2-inch grip strips](#) are pre-cut to 11-inches. This should allow 1/2 - 1-inch overlap over the butt end of the grip. See step 4 before proceeding.

4



Apply 2-inch tape vertically centered along the top of the shaft butt so it overlaps over the back of the shaft. This overlap will be used to seal the end of the shaft. Make sure the tape adheres to all of the shaft by lightly pressing it down.

5



Peel the backing off the tape and cover the shaft butt with the overlapped portion of the tape.

6




Pour into the grip a generous amount of [gripping solvent](#) sealing the vent hole in the butt of the grip with your finger or a golf tee. Close the small end (mouth) of the grip and shake the solution to wet the entire inside wall of the grip.

7




Pour the excess solvent over the entire length of the tape ensuring all the tape is coated. Use a tray to catch the excess solvent for re-use if required. Do not wait too long before going onto the next stage else the solvent will dry out.

8



Hold the grip with the alignment pattern up (facing the front at address is not using a vice) and squeeze the mouth of the grip between the thumb and forefinger to obtain a flared shape. With the applied tape still wet push the flared mouth up and over the shaft butt.

9



Slip the grip on quickly and methodically while the solution is still wet but do not rush, rushing will lead to mistakes. Make sure the grip is on all the way and the butt cap is up against the shaft butt. A slight twisting action may help.

10



Make sure the grip is on straight and the alignment pattern or notches are square to the club face. The grip can be adjusted for about 10 minutes after fitting. If the grip is a ribbed grip, make sure the rib runs straight along the back of the grip. ALLOW AT LEAST 1 HOUR TO DRY